

ebmpapst

Part Number

Operating Instructions

ebm-papst A&NZ Pty Ltd

10 Oxford Road Laverton North VIC 3026 Australia

Phone: +61 3 9360 6400 Fax: +61 3 9360 6464 sales@ebmpapst.com.au www.ebmpapst.com.au

CONTENTS

1.	SAFETY REGULATIONS AND NOTES	1
2.	TECHNICAL DATA	2
2.1	Product drawing	2
2.2	Ancillary component data	2

1. SAFETY REGULATIONS AND NOTES

Please read these operating instructions carefully before starting to work with the device. Observe the following warnings to prevent malfunctions or physical damage to both property and people.

Product W1G200EC9119-CT1 is assembled in Australia and incorporates imported product W1G200EC9119. For product drawing see Chapter 2.1 'Product drawing' of this document and Chapter 2.2 'Ancillary component data' for specifications of sub components.

For safety regulations and information, intended use, technical data, connection and start-up and maintenance, malfunctions, possible causes and remedies refer to operating instructions of W1G200EC9119.

These operating instructions are to be regarded as part of this device. If the device is sold or transferred, the operating instructions must accompany it.

These operating instructions may be duplicated and forwarded for information about potential dangers and their prevention.

 Item no. LS-150.
 Revision 005
 Release 17/02/2016
 Page 1 of 2


ebmpapst


Part Number


Operating Instructions

2. TECHNICAL DATA

2.1 Product drawing







2000mm CABLE WITH 3x BRASS LEAD TIPS CRIMPED NOT SHOWN

DIRECTION OF AIRFLOW "V" ------

All dimensions are in mm

2.2 Ancillary component data

Weight [kg]	TBC
Material of guard grille	Steel phosphate and coated in
	black
Material of wall ring	Sheet steel pre-galvanised and
	coated in black plastic
Type of protection	IP 54